

STEP 3.



If a Pressed Metal Border is also being used this can be put into place now as the panels will sit inside or underneath this. This is done using Liquid Nails and a nail or rivet.

Remembering to mitre the corners or use the available mitre rosette.

Sit the panels in place to check that measurements and cuts are correct, make any necessary adjustments.

STEP 4

You are now ready to fix the panels to the splash back area. Prepare Liquid nails tubes and have soft cloth handy. Also have the Hammer and Nails OR the Pop Rivet Gun and Rivets ready.

Starting in the corner, cover either the back of the sheet or the wall with Heat proof glue and place on the wall into position. Rub over with soft cloth to ensure a bond between the glue, panel and wall.

Continue along the wall with the next panel remembering to overlap the join away from the eye as you walk into the room. once in correct place, rub over the panel with the soft cloth, give the other panel/s a rub over as well while you're at it.

You may find you need a nail or rivet along the join or in the corners, if not even better



STEP 5

Once all your panels are in place you are looking good! Remember to go back and rub over every now and then to ensure a nice tight adhesion to the wall.

The very last steps are to run a bead of silicone along the bench top to panel edge to ensure a water tight seal along the wall. Touch up any nail or rivet heads with matching paint and you are done.

CLEANING.

To retain the Gloss finish on your Powder Coated Splashback, do not use any abrasive cleaners or scourers. The best option is hot soapy water or hot water and Metho or Eucalyptus oil with a Micro-fibre cloth. Simply wipe over the area regularly and it will look great for years to come.



The panel featured in our Kitchen Splash Back area is the Savannah panel and has been topped with the Small Plain Border with mitred corners. The panels and borders have been Powder Coated in 'Mercury Silver'.

ALL SHEET SIZES QUOTED ARE ESTIMATES ONLY. SURFACE SCRATCHES MAY BE PRESENT, POWDER COATING PRIOR TO INSTALL OR PAINTING WITH AN OIL BASED PAINT IS RECOMMENDED.

www.pressedtinpanels.com